

NOTE

- *1: .ABS
.ABS AND ACTIVE STABILITY CONTROL SYSTEM
.AUTOMATED MANUAL TRANSMISSION SYSTEM
.CAN
.CENTRAL DOOR LOCKING SYSTEM
.CHARGING SYSTEM
.COOLING SYSTEM
.ELECTRIC POWER STEERING SYSTEM
.ENGINE CONTROL SYSTEM
.FRONT FOG LAMP
.FUEL WARNING LAMP, OIL PRESSURE WARNING LAMP AND BRAKE WARNING LAMP
.GLOW SYSTEM

- .HEADLAMP
.IMMOBILIZER SYSTEM
.METER AND GAUGE
.MULTI-CENTRE DISPLAY
.PTC HEATER
.ROOM FOG LAMP
.ROOM LAMP AND LUGGAGE COMPARTMENT LAMP
.SEAT BELT WARNING BUZZER
.SEMI-AUTOMATIC AIR CONDITIONER
.SRS
.TURN-SIGNAL LAMP AND HAZARD WARNING LAMP

- *2: .CAN
.CENTRAL DOOR LOCKING SYSTEM
.COOLING SYSTEM
.FRONT FOG LAMP
.FUEL WARNING LAMP, OIL PRESSURE WARNING LAMP AND BRAKE WARNING LAMP
.HEADLAMP
.HEADLAMP LEVELLING SYSTEM
.IMMOBILIZER SYSTEM
.METER AND GAUGE
.MULTI-CENTRE DISPLAY
.POWER WINDOWS
.REAR FOG LAMP


- .REAR WIPER AND WASHER
.ROOM LAMP AND LUGGAGE COMPARTMENT LAMP
.SEAT BELT WARNING BUZZER
.SEMI-AUTOMATIC AIR CONDITIONER
.TAIL LAMP, POSITION LAMP, LICENCE PLATE LAMP AND LIGHTING
.MONITOR BUZZER
.TURN-SIGNAL LAMP AND HAZARD WARNING LAMP
.WINDSHIELD WIPER AND WASHER

- *3: .ABS
.ABS AND ACTIVE STABILITY CONTROL SYSTEM
.AUTOMATED MANUAL TRANSMISSION SYSTEM
.CAN
.CENTRAL DOOR LOCKING SYSTEM
.CHARGING SYSTEM
.COOLING SYSTEM
.ELECTRIC POWER STEERING SYSTEM
.ENGINE CONTROL SYSTEM
.FRONT FOG LAMP
.FUEL WARNING LAMP, OIL PRESSURE WARNING LAMP AND BRAKE WARNING LAMP
.GLOW SYSTEM
.HEADLAMP
.HEADLAMP LEVELLING SYSTEM
.IMMOBILIZER SYSTEM
.METER AND GAUGE

- .MULTI-CENTRE DISPLAY
.POWER WINDOWS
.PTC HEATER
.REAR FOG LAMP
.REAR WIPER AND WASHER
.ROOM LAMP AND LUGGAGE COMPARTMENT LAMP
.SEAT BELT WARNING BUZZER
.SEMI-AUTOMATIC AIR CONDITIONER
.SRS
.STARTING SYSTEM
.TAIL LAMP, POSITION LAMP, LICENCE PLATE LAMP AND LIGHTING
.MONITOR BUZZER
.TURN-SIGNAL LAMP AND HAZARD WARNING LAMP
.WINDSHIELD WIPER AND WASHER


- *4: .ABS
.ABS AND ACTIVE STABILITY CONTROL SYSTEM
.AUTOMATED MANUAL TRANSMISSION SYSTEM
.CAN
.CHARGING SYSTEM
.COOLING SYSTEM
.ELECTRIC POWER STEERING SYSTEM
.ENGINE CONTROL SYSTEM
.FUEL WARNING LAMP, OIL PRESSURE WARNING LAMP AND BRAKE WARNING LAMP
.GLOW SYSTEM
.HEADLAMP
.IMMOBILIZER SYSTEM
.METER AND GAUGE
.MULTI-CENTRE DISPLAY
.PTC HEATER
.SEMI-AUTOMATIC AIR CONDITIONER
.STARTING SYSTEM
.TAIL LAMP, POSITION LAMP, LICENCE PLATE LAMP AND LIGHTING
.MONITOR BUZZER
.WINDSHIELD WIPER AND WASHER

- *5: .ABS
.ABS AND ACTIVE STABILITY CONTROL SYSTEM
.AUTOMATED MANUAL TRANSMISSION SYSTEM
.CAN
.ELECTRIC POWER STEERING SYSTEM
.ENGINE CONTROL SYSTEM
.FUEL WARNING LAMP, OIL PRESSURE WARNING LAMP AND BRAKE WARNING LAMP
.HEADLAMP
.METER AND GAUGE
.MULTI-CENTRE DISPLAY
.TAIL LAMP, POSITION LAMP, LICENCE PLATE LAMP AND LIGHTING
.MONITOR BUZZER
.WINDSHIELD WIPER AND WASHER




B-03

MU801515



B-107

MU801515



B-118

MU801515

